

# Assembly and user instruction



## Assembly procedure

mbiky must only be assembled by an adult. Keep packaging material away from children to avoid suffocation.

### Step 1 – Parts check


Remove all packaging material. Check that all parts are present and examine mbiky for damages.

Parts that should be present:

- Handlebar with grips
- Frame with seat
- Fork with mudguard
- Assembled wheels
- Assembly kit




### Step 2 – Fork attachment



Slide the turning pin through the provided frame hole and glide washer over lower position of turning pin. Hold with one hand frame, washer, turning pin while attaching to the fork. Press the turning pin into the provided fork hole.

### Step 3 – Handlebar attachment



Slide washer over turning pin. Place the toggle nuts into the rear of the fork. Give attention to vertical alignment of the nuts. Place handlebar on top, insert the bolts into the holes and fasten tight. Check gap between frame and handlebar, if washer not fix in place. Remove handlebar and add additional washer.

### Step 4 – Seat adjustment



Check seat height/position for comfortable seating. Readjust if necessary and tighten up the bolts with the provided allen keys. Check seat cover position. Check that all bolts are secure.

Job is done – your mbiky is ready to ride!

## Maintenance and user tips

- Regularly check all screws and nuts to make sure they are tight.
- Make sure a safety helmet is always worn when riding mbiky.
- mbiky is a toy and has neither lights nor brakes and does not comply with road traffic licensing regulations and must not be used on public roads.
- Occasionally check if mbiky shows obvious signs of damage or stress.
- Always be used under adult supervision.
- Clean mbiky with a sponge or cloth and plain water only. If necessary, you can add a few drops of detergent. Dry with a cloth after cleaning.
- Occasionally check the seat for correct height and re-adjust if necessary.
- Store mbiky inside to avoid weather damages.

## Safety warnings

- mbiky is designed for home use and not suitable for commercial purposes.
- mbiky is suitable for children over 2 years old.
- mbiky has a total permissible load bearing capacity of 25kg.
- mbiky must only be assembled by an adult and must be fit to ride before use.
- Keep the packaging material away from children to prevent suffocation.
- mbiky must only be used under adult supervision.
- Children should always wear a safety helmet approved by local standards.
- mbiky must never be used by more than one child at the time.
- Your child must keep both hands on the handlebars while riding mbiky. Your child must not ride without holding the handlebars.
- Always make sure your child wears sturdy shoes when riding mbiky. Never let your child use the mbiky bare feet or wearing open-toe footwear.
- mbiky must only be used on even surfaces.

## Technical data

Adjustable seat height	38 to 44cm
Length	92cm
Weight	5.4kg
Max load capacity	25kg

1 year product warranty

CE  Swiss Quality

Product certification of mbiky

EN71-1: Mechanical and physical properties

EN71-2: Flammability

EN71-3: Migration of certain elements

## Contact

### mbiky Switzerland

Rosenweg 1, 6340 Baar  
Switzerland

Email [info@mbiky.eu](mailto:info@mbiky.eu)

### mbiky China

Unit 2701, Tower 4  
Phase II, Century Garden  
Lane 39, Yin Xiao Road  
Shanghai 201204, China

Email [info@mbiky.eu](mailto:info@mbiky.eu)

### mbiky 中国

中国上海银霄路 39 弄浦东世纪花园二期  
4 号楼 2701 室

邮箱 [info@mbiky.eu](mailto:info@mbiky.eu)